



Universal PTO Removal Tool



PTO Shaft Removal Made Easy.

The universal PTO TOOL gives you the leverage you need to remove your PTO shaft, no matter what type of tractor you have. It helps you to effortlessly separate the implement PTO shaft from the tractor PTO axle.

The fork has been designed to perfectly hug your tractor's PTO stub axle, while the long handle provides the perfect grip, giving you the maximum leverage to get the PTO shaft off, without damaging the shaft itself. A handy and removable ½ inch socket has also been added for extra convenience.

Genuine Parts. Genuine Service. Genuine Reliability.

